

Lighting Literature Selector

LCLC Lighting Control Load Center Literature

-XX = maximum number of DMX controller circuits, **-10, -20, -30** or **-40**
100% neutrals and clip-on breakers only.

LCLC 326-xx..... [DOWNLOAD](#) **PDF**

3Ø, 50A to 100A Main, 22k AIR, up to 26 one-pole or 13 two-pole branch circuits

-XX = maximum number of DMX controller circuits, **-10, -20** or **-30**

LCLC 329-xx..... [DOWNLOAD](#) **PDF**

3Ø, Main Lug Only, 200A bus, up to 29 one-pole or 14 two-pole branch circuits

-XX = maximum number of DMX controller circuits, **-10, -20** or **-30**

LCLC 338-xx..... [DOWNLOAD](#) **PDF**

3Ø, 50A to 100A Main, 22k AIR, up to 38 one-pole or 19 two-pole branch circuits

-XX = maximum number of DMX controller circuits, **-10, -20, -30** or **-40**

LCLC 341-xx..... [DOWNLOAD](#) **PDF**

3Ø, 150A to 225A Main, 25k AIR, up to 41 one-pole or 20 two-pole branch circuits

LCP Lighting Control Panelboard Literature

-XX = maximum number of DMX controller circuits, **-10, -20, -30, -40** or **-50**
200% neutrals, accept bolt-on or clip-on breakers.

LCP 341-xx-M225..... [DOWNLOAD](#) **PDF**

3Ø, 150-225A Main, 65k AIR, up to 41 one-pole or 20 two-pole branch circuits, 200% Neutral

LCP 341-xx-M400..... [DOWNLOAD](#) **PDF**

3Ø, 400A Main, 10k AIR, up to 41 one-pole or 20 two-pole branch circuits, 200% Neutral

LCRP-10 series **Lighting Control Relay Panel** . [DOWNLOAD](#) **PDF**

Contains **4, 8** or **10** DMX controlled 120v or 277v., 20A relays.

DMX Remote Breaker Options [DOWNLOAD](#) **PDF**

To add DMX control of motorized breakers in existing Square D panels.

**LynTec Sound System Sequencing
Literature Selector**

[DOWNLOAD](#) **PDF**